

312243871310 RPTV Lamp

Bare Bulb Installation Guide



The instructions below come with no warranty or guarantee. Improper assembly or use of excessive force may result in damage to your lamp. The buyer assumes full responsibility for damages or problems caused by use of these instructions. Installing this bulb requires a moderate level of technical ability and proficiency in the use of hand tools as well as a general understanding of electronic components.

Important Safety Tips:

- Before touching lamp, bulb and/or other internal parts make sure the projection device has sufficiently cooled down.
- Always handle bulbs with gloves on so that no oils from your hand get on the bulb. If bare hands have touched it, the front glass should be cleaned with a lint free towel before installing the lamp.
- The front glass of the bulb should not make direct contact with metal.
- Direct airflow towards the front glass should be avoided.
- In case of bulb rupture during lamp installation, mercury vapour will be emitted. Avoid inhalation take precautions to avoid prolonged exposure to this mercury vapour. Clean the spilled mercury according to prevailing safety procedures.

To effectively replace your lamp bulb we recommend using the with following tools:




Flathead Screwdriver



Adjustable Wrench



Philips Screwdriver



STEP 1

To begin, you will need to release the wire that secures the bulb to the cage. A small flathead screwdrive can be used to help pry it loose if needed.



STEP 2

Using a philips screwdriver, remove the screw located on the left hand corner of the bulb.

Using a adjustable wrench, remove the nut located at the end of the bulb.



STEP 3

Using a pair of rubber gloves to remove this bulb is recommended. Once the bulb is out, place your new bulb securely inside the cage and repeat the steps in reverse to finish your installation.



PREMIUM POWER
PRODUCTS